


34430 REPLACEMENT FILTER

⚠ WARNING ⚠



- **Always wear eye protection and protective clothing when working with refrigerants. Contact with refrigerant may cause personal injury. Disconnect hoses and tubes with extreme caution as they may contain liquid refrigerant under pressure. Always point hoses away from you and anyone nearby.**
- **To avoid possible hazardous release of refrigerant, follow these steps carefully.**

The 34430 Replacement Filter is for mobile applications only. If you have a microprocessor-controlled station, follow the directions in that station's operating manual to replace the filter. If your station does not have a microprocessor, follow these directions.

1. If recycling is in progress, turn off the **RECYCLING** switch. The compressor continues to operate until refrigerant clears from the suction side of the A/C system.
2. Loosen the nuts at each end of the filter and remove the filter.

3. Install the new 34430 filter. The refrigerant flow arrow on the filter label must point to the left. The word "INLET" stamped on the end of the filter must be on the right.
4. When the filter is in place, evacuate the station for approximately 10 minutes to remove the air that entered during the filter changeout. Attach a vacuum pump to the oil drain port and open the oil drain valve. Start the vacuum pump and operate for the required amount of time.

The station is ready to resume operation.

Because of ongoing product improvements, we reserve the right to change design, specifications, and materials without notice.



*For more information call toll-free
1-800-822-5561 in the continental U.S.
and Canada. In all other locations,
contact your local distributor.*