

# 19740 Inline Strainer Fitting

## ⚠ WARNING ⚠



- Unplug the station before beginning service work. Incorrect use or connections can cause electrical shock.



- Wear safety goggles when working with refrigerants. Refrigerants can cause eye injury.



- Disconnect hoses using extreme caution! Pressurized refrigerant may be present in hoses. Point hoses away from you and anyone nearby.


## Instructions

### Installation

1. Install inline strainer on liquid port of source tank.
2. The low-side adapter will be used for machines without a tank fill hose. Connect source fill hose to fitting.

### Cleaning the Strainer Tip

1. Unscrew fitting and remove strainer tip.
2. Blow debris out of strainer tip with an air hose until clean.
3. Assemble fitting.
4. Install onto tank.



For more information, call TOLL-FREE  
1-800-822-5561 in the continental U.S. and Canada.  
In all other locations, contact your local distributor.

Because of ongoing product improvements, we reserve the right to change design, specifications, and materials without notice.

**ROBINAIR**  
AN SPX BRAND

655 EISENHOWER DRIVE  
OWATONNA MN 55060  
CUSTOMER SERVICE : 1-800-533-6127  
FAX : 1-800-322-2890  
TECHNICAL SERVICE : 1-800-822-5561  
FAX : 1-866-259-1241  
WEBSITE : WWW.ROBINAIR.COM